


Emergency Stop Switches Selection Guide



(Continued on Next Page)

Emergency Stop Switches Selection Guide

(Continued from previous page)

		Model	Mark	
<p>Push-ON</p> <p>Detachable Contact Block</p> <p>Pushlock Pull or Turn Reset</p> <p>ø40mm Button</p>		<p>XW1E-TV4 (Screw Terminal)</p>		
		<p>XW1E-TV4 (Connector)</p>		
	<p>ø30mm Mount Hole</p> <p>New Concept Reverse Energy Structure Safe Break Action</p> <p>Non illuminated</p> <p>Detachable Contact Block</p> <p>Pushlock Pull or Turn Reset</p> <p>ø40mm Button</p> <p>Plastic Bezel</p>		<p>XN1E-BV4 (Plastic Bezel)</p>	
			<p>XN5E-BV4 (Flush Bezel)</p>	
		<p>XN1E-BV5 (Plastic Bezel)</p>		
		<p>XN4E-BL4 (Padlockable)</p>		
	<p>ø40mm Button</p> <p>Plastic Bezel</p>		<p>XN1E-LV4 (Plastic Bezel)</p>	
			<p>XN5E-LV4 (Flush Bezel)</p>	
		<p>XN4E-LL4 (Padlockable)</p>		
	<p>Illuminated</p> <p>Detachable Contact Block</p> <p>Pushlock Pull or Turn Reset</p> <p>ø40mm Button</p> <p>Plastic Bezel</p>		<p>XN1E-TV4 (Plastic Bezel)</p>	
			<p>XN5E-TV4 (Flush Bezel)</p>	
		<p>XN4E-TL4 (Padlockable)</p>		
<p>Push-ON</p> <p>Detachable Contact Block</p> <p>Pushlock Pull or Turn Reset</p> <p>ø40mm Button</p> <p>Plastic Bezel</p>		<p>XN1E-TV4 (Plastic Bezel)</p>		
		<p>XN5E-TV4 (Flush Bezel)</p>		
	<p>XN4E-TL4 (Padlockable)</p>			
<p>Accessories</p> <p>Emergency Stop Nameplate</p> <p>ø16mm Mount Hole</p> <p>ø22mm Mount Hole</p> <p>ø30mm Mount Hole</p>		<p>HAAV</p>		
		<p>HWAU</p>		
		<p>HNAV</p>		