MOCON brings Science to the <u>Art</u> of Leak Detection using the new InFlux[™] method



Determines leak hole size Analyzes O₂ headspace Measures package volume

NEW!

PAC CHECK® Package Integrity Analyzer

Patent pending AccuLeak[™] technology determines the absolute leak size of your package





Equipos de control de calidad

Tel.: (+34) 902 450 160 Fax: (+34) 902 433 088 <u>ermec@ermec.net</u> www.ermec.net



Combination

Leak Detector • O, Headspace Analyzer • Measures Package Volume

Never before has one system given you answers critical in the determination of package shelf-life... fast and accurately!

For use as a research & development tool in package shelf-life studies as well as a quality control device for the measurement of important

headspace and leak parameters.

Benchtop PAC CHECK[®] MODEL 840

Features

- Ability to measure in one quick analysis, three critical variables which determine shelf life
- Calculates the real and absolute leak size in a flexible or semi-rigid package
- Ability to detect channel leaks from 0.0008 0.009" (20-229 micron) diameter at 1/4" (0.64 cm) length and even smaller pinhole leaks.
- Certified NIST traceable leaks for instrument validation
- Benchtop Model 840 with high speed pump for fast analysis of large packages

- Portable Model 820 with a rechargeable battery for online and in-store analysis
- Flo -Smart[™] technology detects any blockage of sample flow into the instrument
- SafePoint[™] probe tip, reusable blunt point pierces the package, not skin
- Alarms Low and High
- Store up to 240 individual product test methods
- Store up to 240 test results that can be sorted by multiple criteria
- Optional PC PAC[™] software available

How much is your package leaking?

Get the answer for a channel or pin hole leak using MOCON's patent pending InFlux™ method

There are several benefits to the InFlux[™] vacuum/flow method utilized in the PAC CHECK Package Integrity Analyzers over traditional positive pressure leak detectors. Benefits to this type of method include:

> Increased sensitivity, accuracy and repeatability
> Eliminates errors caused by package creep, as well as from artificial stresses on package seals
> Leak measurement is not package volume dependent

Ability to calculate three measurements simultaneously-

Portable PAC CHECK[®] MODEL 820

mocon

headspace, leak and volume



PAC CHECK® Models 820/840

Technical Specifications (Preliminary)	
O2% Range:	0.01-100%
Accuracy:	+/- 0.1% Absolute or +/- 2% Relative whichever is greater
Volume Range:	0.1 - 13 liters
Accuracy:	+/- 0.03 liters Absolute or +/-2% Relative whichever is greater
Hole Size Range:	1.0 - 9.0 mils (25.4 - 229 micron) at 0.25" (0.64 cm) channel length
	0.5 – 5.0 mils(12.7 - 127 micron) at 0.01" (254 micron) channel length
Accuracy:	+/- 0.1 mil Absolute or +/-3% Relative whichever is greater
Max Flow Range:	2,500 cc/min for the Model 820
	5,300 cc/min for the Model 840
Pressure Range:	400-800 mmHg
Amb. Temp Range:	10-30C
Amb. Humidity Range:	0-90%RH non-condensating
Power Range:	100-240 volts AC
Frequency Range:	50-60 Hz

NIST Traceable Leaks

2 sizes of leaks come with the instrument to validate system performance.

3 mil (76.2 micron) channel @ 1/4" (0.64 cm) and a 7 mil (178 micron) channel @ 1/4" (0.64 cm)



Patent #6,382,011

Specifications may change as part of our program for continuous product improvement.

For more information, visit our website at www.mocon.com or call **763-493-6370** to

speak with a sales specialist



7500 Boone Avenue North Minneapolis, Minnesota 55428 USA 763-493-6370



Tel.: (+34) 902 450 160 Fax: (+34) 902 433 088 <u>ermec@ermec.net</u> <u>www.ermec.net</u>

Equipos de control de calidad

MOCON and PAC CHECK are registered trademarks and AccuLeak, Flo-Smart, InFlux, PC PAC, and SafePoint are trademarks of MOCON, Inc. All other trademarks are those of their respective holders. Copyright © 2006 MOCON, Inc. All rights reserved. PC 820 - 1, 5/30/06

Optional PC PAC[™] Software

5 different languages available

Ability to sync product names, user names, test results, and test methods between the instrument and the computer.

Optional Verification Standards

- Volume Standard
- O₂ Calibrated Gas