
Think Automation and beyond...



Normal/latched status can be checked from a distance with the mechanical indicator function. The smooth ridge-less button prevents dust build-up and assures comfortable operation.




ERMEC, S.L. BARCELONA C/ Francesc Teixidó, 22 08918 Badalona (España) Tel.:93.450.16.00 Tel.: (+34) 902 450 160 Fax: (+34) 902 433 088 info@ermec.com www.ermec.com ERMEC, S.L. MADRID c/Puerto Rico, 4 28220 Majadahonda (España) Tel.:91.828.56.51 PORTUGAL portugal@ermec.com

BILBAO bilbao@ermec.com

# XW Series

The safety mechanism ensures the XW contacts open (safe) even when damaged by excessive shocks (reverse energy structure, safe break action).

# Excellent safety mechanisms including a mechanical indicator that shows contact status.



Direct Opening Action

All normally closed contact elements of an

K of IEC 60947-5-1. (IEC 60947-5-5; 5.2)

emergency stop devices shall have a direct opening action (positive opening action), according to annex



When the contact block is detached from the operator, the cam directly opens the NC main contacts (contacts are off).

# Ø22 XW Series Emergency Stop Switches (Mechanical Indicator)

#### High level of safety with Safe Break Action. Mechanical indicator on the operator body shows the contact status - green when NC contacts are closed - reducing the maintenance work.

- IDEC's original "Safe Break Action" and "Reverse Energy Structure" ensure the safety of operator and system, when the switch is damaged due to excessive shocks.
- The mechanical indicator on the operator body shows the normal/ latched status (green: normal). Reduces maintenance work and improves operation efficiency.
- Illuminated model also available (same size as non-illuminated)
- The depth behind the panel is only 46.4 mm (w/terminal cover).
- 1 to 4NC main contacts and 1 or 2NO monitor contact
- · Push-to-lock, Pull or Turn-to-reset operator
- · Direct opening action mechanism (IEC 60947-5-5, 5.2, IEC 60947-5-1, Annex K)
- Safety lock mechanism (IEC 60947-5-5, 6.2)
- Degree of protection: IP65 (IEC 60529)
- Durable gold-plated contacts
- Finger-safe structure (IP20)
- UL, c-UL listed. EN compliant.
- UL NISD category

#### Standards

Applicable Standards	Mark	File No. or Organization
UL508 CSA C22.2 No. 14		UL/c-UL Listing File No. E68961
IEC60947-5-5 UL991 NFPA79 EN418	EMERGENCY STOP USTED DEVICE	UL Listing File No. E305148
EN60947-5-1		TÜV SÜD
EN60947-5-5 (Note)	CE	EU low voltage directive
GB14048.5		CCC No. 2012010305589649
GB14048.5		CCC No. 2012010305589649

#### **Contact Ratings** (NC main contacts/NO monitor contact)

	ited Insulat Itage (Ui)	ion	Screw Terminal	250V				
Ra	Rated Thermal Current (Ith)			5A				
Ra	Rated Operating Voltage (Ue)			30V	125V	250V		
		AC	Resistive Load (AC-12)	-	5A	ЗA		
Current	Main	50/60 Hz	Inductive Load (AC-15)	-	ЗA	1.5A		
	Joint Contacts DC   Difference DC   Difference DC   Difference AC   Solver Solver   Monitor Contacts	Resistive Load (DC-12)	2A	0.4A	0.2A			
ating			Inductive Load (DC-13)	1A	0.22A	0.1A		
ber		AC	Resistive Load (AC-12)	-	1.2A	0.6A		
ed O	Monitor	50/60 Hz	50/60 Hz	50/60 Hz	Inductive Load (AC-14)	-	0.6A	0.3A
Rat	Contacts	DC	Resistive Load (DC-12)	2A	0.4A	0.2A		
		00	Inductive Load (DC-13)	1A	0.22A	0.1A		

• Minimum applicable load: 5V AC/DC, 1 mA (reference value)

(Operating area depends on the operating conditions and load types.) The rated operating currents are measured at resistive/inductive load types specified in JIS C8201-5-1.

#### **Illumination Ratings**

	-	
Rated Voltage	Operating Voltage	Rated Current
24V AC/DC	24V AC/DC ±10%	15 mA

Note: An LED lamp is built into the contact block and cannot be replaced.

#### **Specifications**

Specifications	
Applicable Standards	IEC60947-5-5, EN60947-5-5 JIS C8201-5-1, UL508, UL991, NFPA79, CSA C22.2 No. 14, GB14048.5
Operating Temperature	Non-illuminated: –25 to +60°C (no freezing) LED illuminated: –25 to +55°C (no freezing)
Storage Temperature	-45 to +80°C (no freezing)
Operating Humidity	45 to 85% RH (no condensation)
Operating Force	Push to lock: 32N Pull to reset: 21N Turn to reset: 0.27 N·m
Minimum Force Required for Direct Opening Action	80N
Minimum Operator Stroke Required for Direct Opening Action	4.0 mm
Maximum Operator Stroke	4.5 mm
Contact Resistance	50 m $\Omega$ maximum (initial value)
Insulation Resistance	100 M $\Omega$ minimum (500V DC megger)
Overvoltage Category	11
Impulse Withstand Voltage	2.5 kV
Pollution Degree	3
Operation Frequency	900 operations/hour
Shock Resistance	Operating extremes: 150 m/s <sup>2</sup> Damage limits: 1000 m/s <sup>2</sup>
Vibration Resistance	Operating extremes:10 to 500 Hz, amplitude 0.35 mm, acceleration 50 m/s <sup>2</sup> Damage limits: 10 to 500 Hz, amplitude 0.35 mm, acceleration 50 m/s <sup>2</sup>
Mechanical Life	250,000 operations minimum
Electrical Life	100,000 operations minimum 250,000 operations minimum (24V AC/DC, 100 mA)
Degree of Protection	Panel front: IP65 (IEC 60529) Terminal Protection: IP20 (screw terminal, when using XW9Z-VL2MF)
Short-circuit Protection	250V/10A fuse (Type aM, IEC60269-1/IEC60269-2)
Conditional Short- circuit Current	1000A
Terminal Style	M3 screw terminal
Recommended Tightening Torque for Locking Ring	2.0 N⋅m
Connectable Wire	0.75 to 1.25 mm <sup>2</sup> (AWG18 to 16)
Recommended Tightening Torque for Terminal Screw	0.6 to 1.0 N·m

#### **Mechanical Indicator Model**

#### Non-illuminated Pushlock Pull/Turn Reset (Screw Terminal)

Non-illuminated Pushlock Pull/Turn Reset (Screw Terminal)						
Shape	NC Main	NO Monitor	Pa	Button Color		
0.150	Contact	Contact	IP20	w/Terminal Cover	Code	
ø38 mushroom with	1NC	_	XW1E-BV4TG01MFR	XW1E-BV4TG01MR		
mechanical indicator	2NC	_	XW1E-BV4TG02MFR	XW1E-BV4TG02MR		
e 🕲 ss ura Ura Ura Brope Misse Ura Ura Ura Ura Ura Ura Ura Ura	3NC	_	XW1E-BV4TG03MFR	XW1E-BV4TG03MR		
	4NC	_	XW1E-BV4TG04MFR	XW1E-BV4TG04MR		
	1NC	1NO	XW1E-BV4TG11MFR	XW1E-BV4TG11MR	R (red)	
	2NC	1NO	XW1E-BV4TG12MFR	XW1E-BV4TG12MR		
	3NC	1NO	XW1E-BV4TG13MFR	XW1E-BV4TG13MR		
⊖ (€ @⊖	2NC	2NO	XW1E-BV4TG22MFR	XW1E-BV4TG22MR		

• Pushlock pull/turn reset switches are locked when pressed, and reset when pulled or turned clockwise.

• IP20 types can be connected to solid wires only.

#### Illuminated Pushlock Pull/Turn Reset (Screw Terminal)

Shape	Illumi- Rated	NC Main	NO Monitor	Part	Button		
	nation	Voltage	Contact	Contact	IP20	w/Terminal Cover	Color Code
ø38 mushroom with			1NC	—	XW1E-LV4TG01Q4MFR	XW1E-LV4TG01Q4MR	
mechanical indicator			2NC	_	XW1E-LV4TG02Q4MFR	XW1E-LV4TG02Q4MR	
	24	LED 24V AC/DC	3NC	_	XW1E-LV4TG03Q4MFR	XW1E-LV4TG03Q4MR	
			4NC	—	XW1E-LV4TG04Q4MFR	XW1E-LV4TG04Q4MR	
	LED		1NC	1NO	XW1E-LV4TG11Q4MFR	XW1E-LV4TG11Q4MR	R (red)
			2NC	1NO	XW1E-LV4TG12Q4MFR	XW1E-LV4TG12Q4MR	
		3NC	1NO	XW1E-LV4TG13Q4MFR	XW1E-LV4TG13Q4MR		
			2NC	2NO	XW1E-LV4TG22Q4MFR	XW1E-LV4TG22Q4MR	

• Pushlock pull/turn reset switches are locked when pressed, and reset when pulled or turned clockwise.


· IP20 types can be connected to solid wires only.

• LED lamp is not removable.

#### Dimensions

#### Screw Terminal (IP20)

#### Screw Terminal (w/terminal cover)



All dimensions in mm.

Package quantity: 1

BARCELONA ERMEC, S.L. C/ Francesc Teixidó, 22 08918 Badalona ERMEC (España) Tel.:93.450.16.00


Tel.: (+34) 902 450 160 Fax: (+34) 902 433 088 info@ermec.com www.ermec.com

ERMEC, S.L. MADRID c/Puerto Rico, 4 28220 Majadahonda (España) Tel.:91.828.56.51


PORTUGAL portugal@ermec.com

BILBAO bilbao@ermec.com

#### Mounting Hole Layout



#### LED Internal Circuit



### **Terminal Arrangement (Bottom View)**

#### Screw Terminal Non-illuminated



With 1NO monitor contacts NC main contacts: Terminals 1-2 NO monitor contacts: Terminals 3-4

TOP


\*1 \*2

Ŧ

Right Left



\*



\*4 \*3

Right

4

NC main contacts only NC main contacts: Terminals 1-2

TOF

₩ ¥

X1 \*2

and left

Terminals on

1NC:

2NC:

3NC:

**Screw Terminal Illuminated** 


\*2

\*1 X2

Terminals on right

Terminals on right

right, left, and top



NC main contacts:

TOF

X1 \*4

1NC: Terminals on top

2NC: Terminals on right and left

LED ⊊ Ī

\*3 X2

<u>م</u>

Right

With 2NO monitor contacts NC main contacts: Terminals 1-2 NO monitor contacts:



<u>م</u> \*4 \*3 1NC: Terminals on top 2NC: Terminals on right and left

₽.

1NC: Terminals on right 2NC: Terminals on right and left 3NC: Terminals on right.

left, and top

#### Accessories

Package **Description & Shape** Material Part No. Ordering No. Remarks Quantity **Ring Wrench**  Used to tighten the locking ring when installing the XW emergency stop switch onto a panel. Metal (nickel-plated brass) MW9Z-T1 MW9Z-T1 1 110 (weight: approx. 150g) Black Terminal Cover · Used for screw terminals. · Attached to IP20 protection cover units. PPE XW9Z-VL2M XW9Z-VL2MPN02 2 Black **IP20** Protection Cover • Used on terminals for IP20 finger protection. · Only solid wires can be used. XW9Z-VL2MF XW9Z-VL2MFPN02 Polyamide 2 • The IP20 protection cover cannot be removed once installed.

· Screw terminal model has a terminal cover or IP20 protection cover.




Tel.: (+34) 902 450 160 Fax: (+34) 902 433 088 info@ermec.com www.ermec.com

ERMEC, S.L. MADRID c/Puerto Rico, 4 28220 Majadahonda (España) Tel.:91.828.56.51

PORTUGAL portugal@ermec.com

BILBAO bilbao@ermec.com

With 1NO monitor contacts Terminals 3-4





# Ø22 XW Series Emergency Stop Switches (w/Mechanical Indicator)


#### Nameplate (for ø22 Emergency Stop Switches)

Description	Legend	Part No.	Ordering No.	Package Quantity	Material	Plate Color	Legend Color
Button	(blank)	HWAV-0-Y	HWAV-0-Y		Polyamide	Yellow	—
	EMERGENCY STOP	HWAV-27-Y	HWAV-27-Y	1			Plack
	EMERGENCY OFF	HWAV-74-Y	HWAV-74-Y				Black

#### **Maintenance Parts**

Description & Shape	Material	Part No.	Ordering No.	Package Quantity	Remarks	N
Locking Ring						
	Polyamide	CW9Z-LN	CW9Z-LNPN05	5	• Black • ø27.8, t = 5.0	

#### Dimensions



All dimensions in mm.


# ▲ Safety Precautions

- Turn off power to the XW series emergency stop switch before starting installation, removal, wiring, maintenance, and inspection of the relays. Failure to turn power off may cause electrical shock or fire hazard.
- For wiring, use wires of the proper size to meet the voltage and current requirements. Tighten the M3 terminal screw to a tightening torque of 0.6 to 1.0 N·m. Failure to tighten the terminal screws may cause overheating and fire.

## Instructions

#### **Removing the Contact Block**

First unlock the operator button. Grab the bayonet ring ① and pull back the bayonet ring until the latch pin clicks ②, then turn the contact block counterclockwise and pull out ③.




#### Notes for removing the contact block

- 1. When the contact block is removed, the monitor contact (NO contact) is closed.
- 2. While removing the contact block, do not exert excessive force, otherwise the switch may be damaged.
- 3. An LED lamp is built into the contact block for illuminated pushbuttons. When removing the contact block, pull the contact block straight to prevent damage to the LED lamp. If excessive force is exerted, the LED lamp may be damaged and fail to light.


#### **Panel Mounting**

Remove the locking ring from the operator. Insert the operator from panel front into the panel hole. Face the side without thread on the operator with TOP marking upward, and tighten the locking ring using ring wrench MW9Z-T1 to a torque of 2.0 N·m maximum.




#### Installing the Contact Block

First unlock the operator button. Align the small  $\checkmark$  marking on the edge of the operator with the small  $\blacktriangle$  marking on the yellow bayonet ring. Hold the contact block, not the bayonet ring. Press the contact block onto the operator and turn the contact block clockwise until the bayonet ring clicks.



#### Notes for installing the contact block

Make sure that the bayonet ring is in the locked position. Check that the two projections on the bayonet ring are securely in place.




Solid Wire

#### Instructions

#### Wiring

1. Wire thickness: 0.75 to 1.25 mm<sup>2</sup> (AWG18 to 16)

#### Applicable Crimping Terminals




• Be sure to install an insulating tube on the crimping terminal.

2. Tighten the M3 terminal screw to a tightening torque of 0.6 to 1.0  $$\rm N{\cdot}m$.$ 


### **Installing & Removing Terminal Covers**

#### XW9Z-VL2M

To install the terminal cover, align the TOP marking on the terminal cover with the TOP marking on the contact block. Place the two projections on the bottom side of the contact block into the slots in the terminal cover. Press the terminal cover toward the contact block.




To remove the terminal cover, pull out the two latches on the top side of the terminal cover. Do not exert excessive force to the latches, otherwise the latches may break.



#### IP20 Protection Terminal Cover XW9Z-VL2MF

To install the IP20 protection cover, align the TOP marking on the cover with the TOP marking on the contact block, and press the cover toward the contact block.



Notes:

- 1. Once installed, the XW9Z-VL2MF cannot be removed.
- 2. The XW9Z-VL2MF cannot be installed after wiring.
- 3. With the XW9Z-VL2MF installed, crimping terminals cannot be used. Use solid wires.
- Make sure that the XW9Z-VL2MF is securely installed. IP20 cannot be achieved when installed loosely, and electric shocks may occur.

#### **Contact Bounce**

When the button is reset by pulling or turning, the NC main contacts will bounce. When pressing the button, the NO monitor contacts will bounce.


When designing a control circuit, take the contact bounce time into consideration (reference value: 20 ms).

#### LED Illuminated Switches

An LED lamp is built into the contact block and cannot be replaced.

#### Nameplate

When anti-rotation is not required, remove the projection from the nameplate or switch guard using pliers.



#### Handling

Do not expose the switch to excessive shocks and vibrations, otherwise the switch may be deformed or damaged, causing malfunction or operation failure.



ERMEC, S.L. BARCELONA C/ Francesc Teixidó, 22 08918 Badalona ERMÈC (España) Tel.:93.450.16.00

Tel.: (+34) 902 450 160 Fax: (+34) 902 433 088 info@ermec.com www.ermec.com

ERMEC, S.L. MADRID c/Puerto Rico, 4 28220 Majadahonda (España) Tel.:91.828.56.51

E-mail: marketing@idec.co.jp

6-64, Nishi-Miyahara 2-Chome, Yodogawa-ku, Osaka 532-0004, Japan Tel: +81-6-6398-2571, Fax: +81-6-6392-9731

PORTUGAL portugal@ermec.com

BILBAO bilbao@ermec.com

Specifications and other descriptions in this catalog are subject to change without notice.

**IDEC CORPORATION** 

# IDEC **IDEC CORPORATION (USA)**

1175 Elko Drive Sunnyvale, CA 94089-2209, USA Tel: +1-408-747-0550 / (800) 262-IDEC (4332) Fax: +1-408-744-9055 / (800) 635-6246 E-mail: opencontact@idec.com IDEC CANADA LIMITED 3155 Pepper Mill Court, Unit 4 Mississauga, Ontario, L5L 4X7, Canada Tel: +1-905-890-8561 Toll Free: (800) 262-IDEC (4332) Fax: +1-905-890-8562 E-mail: sales@ca.idec.com IDEC AUSTRALIA PTY. LTD. Unit 17, 104 Ferntree Gully Road, Oakleigh, Victoria 3166, Australia Tel: +61-3-8523-5900, Toll Free: 1800-68-4332 Fax: +61-3-8523-5999 E-mail: sales@au.idec.com

IDEC ELECTRONICS LIMITED Unit 2, Beechwood, Chineham Business Park, Basingstoke, Hampshire RG24 8WA, UK Tel: +44-1256-321000, Fax: +44-1256-327755 E-mail: sales@uk.idec.com IDEC ELEKTROTECHNIK GmbH Wendenstrasse 331, 20537 Hamburg, Germany Tel: +49-40-25 30 54 - 0, Fax: +49-40-25 30 54 - 24 E-mail: service@idec.de IDEC (SHANGHAI) CORPORATION Room 701-702 Chong Hing Finance Center, No. 288 Nanjing Road West, Shanghai 200003, PRC Tel: +86-21-6135-1515 Fax: +86-21-6135-6225 / +86-21-6135-6226 E-mail: idec@cn.idec.com IDEC (BEIJING) CORPORATION Room 211B, Tower B, The Grand Pacific Building, 8A Guanghua Road, Chaoyang District, Beijing 100026, PRC Tel: +86-10-6581-6131, Fax: +86-10-6581-5119

IDEC (SHENZHEN) CORPORATION Unit AB-3B2, Tian Xiang Building, Tian'an Cyber Park, Fu Tian District, Shenzhen, Guang Dong 518040, PRC Tel: +86-755-8356-2977, Fax: +86-755-8356-2944 IDEC IZUMI (H.K.) CO., LTD. Units 11-15, Level 27, Tower 1, Millennium City 1, 388 Kwun Tong Road, Kwun Tong, Kowloon, Hong Kong Tel: +852-2803-8989, Fax: +852-2565-0171 E-mail: info@hk.idec.com **IDEC TAIWAN CORPORATION** 8F-1, No. 79, Hsin Tai Wu Road, Sec. 1, Hsi-Chih District, 22101 New Taipei City, Taiwan Tel: +886-2-2698-3929, Fax: +886-2-2698-3931 E-mail: service@tw.idec.com IDEC IZUMI ASIA PTE. LTD. No. 31, Tannery Lane #05-01, HB Centre 2, Singapore 347788 Tel: +65-6746-1155, Fax: +65-6844-5995 E-mail: info@sg.idec.com

Cat. No. EP1470-0-1 APRIL PDF (13/04/04)